

## Couplings & Caps (Cont.)



PART NO.	DESCRIPTION
4 - CAP	1/4" NPS(F) x CAP
6 - CAP	3/8" NPS(F) x CAP
4B - CAP	1/4" BSP(F) x CAP
6B - CAP	3/8" BSP(F) x CAP

## Adaptors



PART NO.	DESCRIPTION
2T - 2B	1/8" NPT(M) x 1/8" BSP(M)
2T - 4	1/8" NPT(M) x 1/4" NPS(M)
2T - 4T	1/8" NPT(M) x 1/4" NPT(M)
2T - 6	1/8" NPT(M) x 3/8" NPS(M)
4 - 2BSP - 316	1/4" NPS(M) x 1/8" BSP(M)
4 - 6	1/4" NPS(M) x 3/8" NPS(M)
4T - 4	1/4" NPT(M) x 1/4" NPS(M)
4T - 4B	1/4" NPT(M) x 1/4" BSP(M)
4T - 6	1/4" NPT(M) x 3/8" NPS(M)
6 - 6	3/8" NPS(M) x 3/8" NPS(M)
6T - 4	3/8" NPT(M) x 1/4" NPS(M)
6T - 4T	3/8" NPT(M) x 1/4" NPT(M)
6T - 6 - 316	3/8" NPT(M) x 3/8" NPS(M)
6T - 6T	3/8" NPT(M) x 3/8" NPT(M)
8T - 6	1/2" NPT(M) x 3/8" NPS(M)



PART NO.	DESCRIPTION
4 - 4T(F)	1/4" NPS(M) x 1/4" NPT(F)
6 - 4T(F)	3/8" NPS(M) x 1/4" NPT(F)
6 - 6T(F)	3/8" NPS(M) x 3/8" NPT(F)



PART NO.	DESCRIPTION
4 - 6TF - 316	1/4" NPS(M) x 3/8" TF
6 - 6TF	3/8" NPS(M) x 3/8" TF
6 - 6TF - 316	3/8" NPS(M) x 3/8" TF
6T - 12mm TF	3/8" NPT(M) x 12mm Tube Fitting
6T - 10mm TF	3/8" NPT(M) x 10mm Tube Fitting



PART NO.	DESCRIPTION
4 - 4RB - 316	1/4" NPS(M) x 1/4" NPS(M) Bulkhead
4B - 4RBB - 316	1/4" BSP(M) x 1/4" BSP(M) Bulkhead
6 - 6RB	3/8" NPS(M) x 3/8" NPS(M) Bulkhead
6B - 6RBB	3/8" BSP(M) x 3/8" BSP(M) Bulkhead
6T - 6RB - 316	3/8" NPT x 3/8" NPS(M) Bulkhead



PART NO.	DESCRIPTION
4SN - 2T	1/4" NPS(F) x 1/8" NPT(M)
4SN - 4	1/4" NPS(F) x 1/4" NPS(M)
4SN - 4T	1/4" NPS(F) x 1/4" NPT(M)
4SN - 6	1/4" NPS(F) x 3/8" NPS(M)
4SN - 6T	1/4" NPS(F) x 3/8" NPT(M)
4SNB - 4B	1/4" BSP(F) x 1/4" BSP(M)
6SN - 2T	3/8" NPS(F) x 1/8" NPT(M)
6SN - 4	3/8" NPS(F) x 1/4" NPS(M)
6SN - 4T	3/8" NPS(F) x 1/4" NPT(M)
6SN - 6T	3/8" NPS(F) x 3/8" NPT(M)
6SNB - 4B	3/8" BSP(F) x 1/4" BSP(M)
6SN - 8T	3/8" NPS(F) x 1/2" NPT(M)

## Adaptors (Cont.)



PART NO.	DESCRIPTION
6SN - 6BTF	3/8" NPS(F) x 3/8" BTF
6SN - 6BTF - 316	3/8" NPS(F) x 3/8" BTF
6SN - 8BTF	3/8" NPS(F) x 1/2" BTF
6SN - 8BTF - 316	3/8" NPS(F) x 1/2" BTF
6SN - 10MBTF - 316	3/8" NPS(F) x 10mm BTF



PART NO.	DESCRIPTION
6TF - 6BTF - 316	3/8" TF x 3/8" BTF



PART NO.	DESCRIPTION
6SN - 6TF - 316	3/8" NPS(F) x 3/8" TF
6SN - 4TF	3/8" NPS(F) x 1/4" TF
6SN - 8TF - 316	3/8" NPS(F) x 1/2" TF



PART NO.	DESCRIPTION
6TF - 6RB - 316	3/8" TF x 3/8" NPS(M)RB
8TF - 6RB - 316	1/2" TF x 3/8" NPS(M)RB

See page 15 for bulkhead adaptor hole sizes.



PART NO.	DESCRIPTION
4SN - 4JIC	1/4" NPS(F) x 1/4" JIC/AN
4 - 4JIC	1/4" NPS(M) x 1/4" JIC/AN
4 - 6JIC	1/4" NPS(M) x 3/8" JIC/AN
6 - 4JIC	3/8" NPS(M) x 1/4" JIC/AN
6 - 6JIC	3/8" NPS(M) x 3/8" JIC/AN



PART NO.	DESCRIPTION
6 - 6TUBE	3/8" NPS(M) x 3/8" OD Tube
6T - 6TUBE	3/8" NPT(M) x 3/8" OD Tube
6 - 8TUBE	3/8" NPS(M) x 1/2" OD Tube
6T - 8TUBE	3/8" NPT(M) x 1/2" OD Tube



PART NO.	DESCRIPTION
DR1 - 2 - 4	1/4" NPS(M)



PART NO.	DESCRIPTION
4 - 2BSP - AWS - 316	1/4" NPS(M) X AW Flow Meter - Short
4 - 2BSP - AWL - 316	1/4" NPS(M) X AW Flow Meter - Long